Modbus/BACnet IP Gateway BAM-360

User Manual

REV 1.3



SiboTech Automation Co., Ltd.

Technical Support: +86-21-5102 8348 E-mail: support@sibotech.net

User Manual

Catalog

1 Product Overview	
1.1 Product Function	3
1.2 Product Features	
1.3 Technical Specifications	
2 Hardware Descriptions	
2.1 Product Appearance	5
2.2 Indicators	6
2.3 Configuration Switch.	6
2.4 Interface	7
2.4.1 Power Interface	7
2.4.2 Ethernet Interface	8
2.4.3 RS-232/RS-485 Interface	9
3 Software Instructions	
3.1 Notes before Configuration	
3.2 Quick Start Guide	
3.3 Scan Equipment	
3.3.1 Scan All Equipment of Ethernet	
3.3.2 IP Search	14
3.4 Configuration	15
3.4.1 Configure Ethernet Parameters	
3.4.2 Configure Serial and Modbus Parameters	17
3.4.3 Configuration Commands	
3.5 Locate	21
3.6 Remote Reset	
3.7 Open Configuration/Save Configuration	23
4 Typical Application	25
5 Installation	
5.1 Machine Dimension	
5.2 Installation Method	27





1 Product Overview

1.1 Product Function

BAM-360 is a gateway which can exchange data between Modbus serial protocol to the BACnet IP protocol. The gateway acts as the slave at the BACnet IP side and the master at the Modbus side.

1.2 Product Features

- Redundant power supply;
- Two independent RS485 interfaces or RS232 interfaces with 1KV optical isolation;
- Ethernet 10/100M adaptive;
- Network security settings;
- Provides online scanning and configuration;
- Modbus command has auto demotion function and error handling functions;
- Easy-to-use configuration software BM-123.

1.3 Technical Specifications

[1] The gateway can achieve the communication between BACnet and Modbus;

[2] Ethernet 10/100M adaptive;

[3] Supports up to 500 BACnet BIs, 300 BOs, 300 BVs, 500 AIs, 300AOs, 300 AVs, 500 MSIs and 100MSOs;

[4] BACnet IP can achieve the following services: Who Is, I Am, Who Has, I Have, Read Property, Write Property, Read Property Multiple;

[5] Each serial port can support up to 100 commands;

[6] Serial interface is RS485 or RS232, half-duplex, and baud rate support: 1200, 2400, 4800, 9600, 19200,

38400, 57600 and 115200 bps; parity support: none, odd, even, mark, space; 1 or 2 stop bits optional;

[7] Two independent RS485 interfaces or RS232 interfaces with 1KV optical isolation;

www.sibotech.net/en

[8] Power supply: 24VDC (11V ~ 30V), 90mA (24VDC);

- [9] Operating temp: -4°F to 140°F (-20°C to 60 °C), relative humidity: 5% ~ 95% (non-condensing);
- [10] External dimension (W*H*D): 1.57 in*4.92 in*4.33 in (40mm*125mm*110mm);
- [11] Installation: 35mm DIN rail;
- [12] Protection class: IP20;
- [13]Test standard: EMC test standards.





2 Hardware Descriptions

2.1 Product Appearance






User Manual

2.2 Indicators

Indicators	State	Description			
	Green On	IP address with no confliction			
ENS	Red On	IP address with confliction			
	Red Blinking	DHCP, BOOTP, IP address conflict detection			
SNS	Green On	BACnet IP interface data is received or transmitted			
2112	Green Blinking	BACnet IP interface data is not received or transmitted			
ENS (Orange) and SNS	Simultaneously On	At the power on moment			
(Orange)	Blink Alternately	Configuration Mode			
(Orange: Red and green on	Blink Alternately (for 3	Lize leasting function			
at the same time)	seconds)	Use locating function			
Serial I TX	Green Blinking	Serial data sending			
Senaria	OFF	No serial data is sending			
Serial I RX	Green Blinking	Serial data receiving			
Senai I KA	OFF	No serial data is receiving			
Serial II TX	Green Blinking	Serial data sending			
	OFF	No serial data is sending			
Serial II RX	Green Blinking	Serial data receiving			
Schaill KA	OFF	No serial data is receiving			

2.3 Configuration Switch

Configuration switch is located on the bottom of the gateway, bit 1 is mode bit, and bit 2 is function bit.





User Manual


Mode (Bit 1)	Function (Bit 2)	Mode	Description
			BACnet IP and Modbus RTU data can be exchanged;
Off	Off	Run mode	Allow reading and writing configuration data. After
Oli	OII	Kull mode	reconfiguring BAM-360, it needs to restart. Then, the
			configuration will take effect.
Off	0	Deen meede	BACnet IP and Modbus RTU data can be exchanged, prohibit
Off	On	Run mode	reading and writing configuration data.
		Configuration	IP address is fixed at 192.168.0.188; this mode can only read
On	Off	C	and write configuration data but cannot communicate between
		Mode	BACnetIP and Modbus RTU.
		Configuration	IP address is fixed at 192.168.0.188; this mode can only read
On	On		configuration data but cannot communicate between BACnetIP
		Mode	and Modbus RTU.

Note: Restart BAM-360 (power off and power on) after reconfiguring the configuration and the configuration will take effect!

2.4 Interface

2.4.1 Power Interface

BAM-360 uses a 24V DC power supply; it has two power interfaces with redundancy function. Users can use one or two power supply.




Pin	Function				
1	GND				
2	NC (Not Connected)				
3	24V+, DC				




If users need to use one power supply for backup, when one supply fails, another power can continue to supply power to ensure the normal operation of the equipment.

Power wiring is shown as below:



2.4.2 Ethernet Interface

Ethernet interface uses RJ-45 connector, 10/100M adaptive. The pin definition (standard Ethernet signal) is shown as below:






User Manual

Pin	Description
S1	TXD+, Tranceive Data+, Output
S2	TXD-, Tranceive Data-, Output
S3	RXD+, Receive Data+, Input
S4	Bi-Directional Data+
S5	Bi-Directional Data-
S6	RXD-, Receive Data-, Input
S7	Bi-Directional Data+
S8	Bi-Directional Data-


2.4.3 RS-232/RS-485 Interface

BAM-360 supports standard dual port RS232 or RS-485. RS232 interface pins are defined as follows:



Pin	Function
1	TX, connect with TX of user device
2	RX, connect with RX of user device
3	GND

RS485 interface pins are defined as follows:





User Manual

Pin	Function
1	B+, RS485
2	A-, RS485
3	GND

The RS-485 interface of BAM-360 is a standard one, and the RS-485 characteristics of the product are shown

as follows:

1. The basic characteristics of RS-485 transmission technology

①Network topology: Linear bus, there are active bus terminal resistors at both sides.

⁽²⁾Transmission rate: 1200 bps~115.2Kbps.

⁽³⁾Media: Shielded twisted-pair cable and also can cancel the shielding, depending on environmental conditions (EMC).

(4)Site number: 32 stations per subsection (without repeater), and can increase up to 127 stations (with repeater).

⑤Plug connection: 3-pin pluggable terminal.


2. The main points on the installation of RS-485 transmission equipment

①All the equipment are connected with RS-485 bus;

②Each Subsection can be connected up to 32 sites;

3The farthest two end of the bus has a terminal resistor - 120 Ω 1/2W to ensure reliable operation of the network.





When RS485 communicates under the point-to-multipoint mode, in order to prevent the reflection and interference of the signal, it requires connecting a terminal resistor in the farthest two ends of the each line; the parameter is $120\Omega \ 1/2W$. There are no parallel terminal resistors at the serial port side of BAM-360.



3 Software Instructions

Double click the software application and install the configuration software BM-123. You can easily follow the prompts to complete the installation, then open the installed configuration software and begin to configure the BAM-360.

Notes: The factory network setting of BAM-360 is DHCP. If the network does not have the DHCP server, the configuration switch (bit 1) should be in the configuration state (on), restart BAM-360 gateway to let the settings take effect. The IP address of BAM-360 is fixed 192.168.0.188, subnet mask is 255.255.255.0 and gateway address is 192.168.0.1.

3.1 Notes before Configuration

BM-123 is a product based on Windows platform, and used to configure parameters of BAM-360.

Please make sure the user's computer and the BAM-360 which need to be configured are in the same network before you run the software.

Search equipment	No.	Туре	IP_ad	MAC_a	Firmw	Name	State
IP Search							
Locate							
Configuration							
Remote Reset							
ommunication Test						Exit	

Double click the icon to access the main interface:





3.2 Quick Start Guide

- > Correctly wire the power line, network cable and RS485 cable;
- Power on the BAM-360 gateway;
- According to actual field condition of your Modbus slave device, modify the BAM-360 configuration according to this manual and download the configuration to the gateway;
- Connect with the Modbus slave devices;
- Connect with the BACnet IP master;

3.3 Scan Equipment

Before configuring parameters of BAM-360, the user need search the gateway using the software. The software provides two ways to search the gateway for the user.

3.3.1 Scan All Equipment of Ethernet

Click "Search equipment" button of the main interface, the software will search all of the available BAM-360 equipment and list them in the main interface.

earch equipment	No.	Туре	IP_ad	MAC_a	Firmw	Name	State
IP Search							
Locate							
Configuration							
Remote Reset							
mmunication Test							



www.sibotech.net/en



3.3.2 IP Search

Click "IP Search" button of the main interface will pop up a dialog box, and user need to enter the IP address of the equipment.

Search equipment	. Туре	IP_ad	MAC_a	Firmw	Name	State
IP Search						
Locate						
Configuration						
Remote Reset						
ommunication Test						

After entering the correct IP address, the software will search BAM-360 with this IP address in the network, and list the information of the equipment in the main interface.



User Manual

Search equipment	No.	Туре ВАМ-360	IP_ad 192.1	MAC_a	Firmw	Name Test	State Allow
		DAM 300	194. 1	00 40	1.0	1681	ATTOW
IP Search							
Locate							
Configuration							
Remote Reset							
ommunication Test							

Note: If the users select the "IP search", users need to enter correct IP address or it will not search equipment.

3.4 Configuration

Select the equipment to be configured in the list, and the function like "Locate", "Configuration", "Remote Reset", "Import" and "Export" will become available:



User Manual

3 1 -123 Gataway Co	nfiguratio	n Software					
Search equipment	No.	Type BAM-360	IP_ad 192.1	MAC_a 00-40	Firmw 1.0	Name Test	State Allow
IP Search							
Locate							
Configuration							
Remote Reset							
Communication Test		Open				Exit	

Click "Configuration" button will pop up the window:

Device	Confi	guration	BACnet Object			
BACnet IP Server	Device name	Test				
Modbus Master I	Assign IP Mode	Manual Assign				
😪 Node(1)	IP Address	192.168.0.10				
Read Holding Registe	Subnet Mask	255, 255, 255, 0				
	Default Gateway	192.168.0.1				
💼 Preset Multiple Regist	DNS1	0.0.0				
Modbus Master II	DNS2	0.0.0				
	Byte-exchange	Disable				
	BACnet IP Port	47808				
	Device Instance	100				
	1		Hrint			
	You can config the following parameter. Assign IP Mode, IP Address, Subnet Mask, Default Gateway, DNS1, DNS2, BACnet IP Port and BACnet IP Device Instance.					
	Tod can coming the following h	arameter Assign ir Mode,ir Address,Suonet Mask,Dei	un Gateway, Divor, Divoz, DAChet ir Font and DAChet ir L	evice instance.		

3.4.1 Configure Ethernet Parameters

Ethernet parameters include: "Device name", "Assign IP mode", "IP Address", "Subnet mask", "Default Gateway", "DNS1", "DNS2".



User Manual

Configuration			
Device	Confi	guration	
BACnet IP Server Modbus Master I Preset Multiple Regist Modbus Master II Modbus Master II	Device name Assign IP Mode IP Address Subnet Mask Default Gateway DNS1 DNS2 Byte-exchange BACnet IP Port Device Instance	Test Manual Assign 192.168.0.10 255.255.255.0 192.168.0.1 0.0.0 0.0.0 Disable 47808 100	

- Custom Name Enter a name used to identify the device in order to distinguish from other devices;
 Note: The name cannot have spaces, up to 16 characters.
- Assign IP Mode Set the IP address assign mode of the device;
- IP address Set the IP address of the device;
- Subnet Mask Set the subnet mask of the device;
- Default Gateway Set the gateway address for the device;
- DNS1 The first domain name server (LAN cannot set);
- DNS2 Standby domain name server;
- Byte swap Does not currently support;
- BACnet IP port Set the BACnet IP port number of BAM-360;
- Device instance Set device instance number BAM-360.

3.4.2 Configure Serial and Modbus Parameters

Serial parameters include: "Baud rate", "Parity", "Stop bits" and "Data bits" etc.



User Manual

Configuration					
Device	Configuration			BACnet Object	
BACnet IP Server Modbus Moster Preset Multiple Regist Modbus Master II	Baud rate Data bits Check bit Stop bits Transmission Mode Response timeout Delay between Polls Output Mode Scan Rate Enable auto demotion when Enable auto demotion, the	20000		BACnet Object	
	You can config the following parameter B	aud rate and so on	Hrint	Export	Exit
< >>	Auto Assign Object Name	Download	Save	Export	Exit

- Baud rate 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400;
- Data bits 8 (currently only support 8 data bits);
- Parity None, Odd, Even, Mark, Space;
- Stop bit 1, 2;
- Transmission mode -RTU;
- Response timeout When the Modbus master send commands, the time waiting for response from the slave, the range is 300~60000ms;
- Delay between polls After one Modbus command has been sent and has received correct response, the delay time before next command being sent, the range is: 0 ~ 2500ms;
- Output Mode Modbus write command (command output) has two output modes: cycle and change of value output;

Change of value: When the output data has changed, it outputs the write command and stop outputting after receiving correct response;

- Cycle: the same with Modbus read command output mode, and output according to the scan rate;
- Scan rate Ratio of slow scan cycle to fast scan cycle;
- Automatic demotion After n times Modbus command response failure to automatically degrade to slow scan;

 Enter automatic Demotion after N times commands failure - set the Modbus command times which need to be resent with no response;


Automatic demotion time - A fast scan command degrades to a slow scan command time, after which automatically restore to fast scan;

How to action with Read command failure – After Modbus read command fails, how the gateway deal with BACnet input object: hold and clear; Hold is to keep the last correctly read values; clear is that the corresponding BACnet input object is cleared.

Note: The gray parts cannot be changed.

3.4.3 Configuration Commands

1. Increase and delete nodes. Right-click the "Modbus Master I", choose "Add Node".




Right click the node and select "Delete Node".



2. Add command

Right click "Node (x)" and select "Add Command".





User Manual	14441635	
Modbus Master I	Connand	
I Read Holding Registe: I Preset Multiple Regist Modbus Master II	01 Read Coil Status 02 Read Input Status 03 Read Holding Register 04 Read Input Register 05 Force Single Coil 06 Preset Single Register 07 Read Exception Status 08 Diagnostics 11 Fetch Comm Event Ctr 12 Fetch Comm Event Log 13 Program Controller 14 Poll Controller 15 Force Multiple Coils 16 Preset Multiple Registe	ſS

Select one command; double click to add the command;

For each Modbus commands' setting, BM-123 will automatically map the Modbus commands to the corresponding BACnet objects after configuring.

Configuration								
Device	Configura	tion			BACnet Obje	ct		
	Function Code	3	Object Type	Object Name	Register Co	unt Data Type	Scale	
😑 퇯 Modbus Master I	Starting Address	0	AI	AI1	1	UINT16	1.00	
	Number of Register	2	AI	AI2	1	UINT16	1.00	
💼 Read Holding Registe	Mapping Address(HEX)							
I Preset Multiple Regist	Mapping Bit	0						
	Number of Byte	0						
🤹 Modbus Master II	Byte-exchange	Non-exchange						
	Type of Check	CRC						
	Type of Scan	Fast Scan						
	Mnemonic							
	·							
	· · · · · · · · · · · · · · · · · · ·							
			Hrint					
	There are two huffers in the gatewa	y, one is input buffer and the other is out		g address refer to th	e two huffers' add	tress it hase zero		
	rest at the content at the Batewa	y, one is input conter and the Shifer is Con	e ar e antor, rivro aro mappu.	-D	o chi o como dat			
			<i>c</i>			6		
< >	Auto Assign Object Name	Download	Save	E	İxport	Exit		

Read coil Status - fill in the number of data, automatically mapped to BACnet BI (binary input). Take above picture as an example;



Read input status - mapped to BACnet BI (binary input);

Read Holding Registers - mapped to BACnet AI (analog input) or MI (multistate input); as is shown below,

left click the "AI" will pop up the drop-down the menu.

Device	Configu	ration			BACnet Object		
- 🔙 BACnet IP Server	Function Code	3	Object Type	Object Name	Register Count	Data Type	Scale
🔙 Modbus Master I	Starting Address	0	AI	AT1	1	UINT16	1.00
- Se Node(1)	Number of Register	2	AI	V AI2	1	UINT16	1.00
Read Holding Registe	Mapping Address(HEX)		AL				
Precet Multiple Registe		0	MI				

See picture above:

- Object type: AI and MI optional, default is AI;
- Object Name: Editable, the maximum data length it supports is 12;
- Register Count: 1 and 2 optional, default is 1 (Map one Modbus register to a BACnet object);
- Data Types : BOOL, INT16 (signed 16-bit integer data), UINT16 (unsigned 16-bit integer data), INT32 (signed 32-bit integer data), INT32V (INT32 Inverse, contrary to high and low word INT32), UINT32 (unsigned 32-bit integer data), UINT32V (UINT32 Inverse, contrary to high and low word of UINT32), Float, and FloatV (Float Inverse, contrary to high and low word of Float) optional (different display for different types of BACnet object);
- Scaling: You can edit, range: 0.01 to 100, default: 1.0

Read Input Register - mapped to BACnet BO (binary output) or MI (multistate input), Optional;

Write Single Coil -mapped to BACnet BO (binary output) or BV (binary value), Optional;

Write Single Register -mapped to BACnet AO (analog output), AV (analog value) or MO (multistate output), Optional;

Write Multiple Coils - mapped to BACnet BO (binary output) or BV (binary value), Optional;

Preset Multiple Registers - mapped to BACnet AO (analog output), AV (analog value) or MO (multistate output), Optional;

3.5 Locate

When users manage multiple BAM-360 gateways, the "locate" function can be used to determine which device you are configuring.

Users click on the "locate" button and the device is still in the network, two orange indicator of the device



alternately blinks a few seconds in order to find the device.

Search equipment	No.	Туре	IP_ad	MAC_a	Firmw	Name	State
Search edephicin	01	BAM-360	192.1			Test	Allow
IP Search							
Locate							
Configuration							
Remote Reset							
ommunication Test							

3.6 Remote Reset

The function of "remote reset" is restarting the selected device. Select the equipment in the list first, click "Remote reset" button, it will pop up a confirmation dialog, then click "OK" to complete the operation.

Search equipment	No.	Type		MAC_a			State
	01	BAM-360	192.1	00-40	1.0	Test	Allow
IP Search							
Locate							
Configuration							
Remote Reset							
ommunication Test							



www.sibotech.net/en

3.7 Open Configuration/Save Configuration

• Open the configuration - open and display the configuration data which is saved on the computer;

Search equipment	No.	Type	IP_ad	MAC_a			State
	01	BAM-360	192.1	00-40	1.0	Test	Allow
IP Search							
Locate							
Configuration							
Remote Reset							
communication Test			~			r	

- Export to Excel the configuration parameters are saved to the computer (xls), one-to-one mapping relationship of each Modbus command and BACnet objects. They can easily be seen from the export of Excel;
- Save save the configuration parameters to a computer (. chg), for later viewing, attention to save this file;





• Select the device in the list, click on the "save" or "Export" button and select the path to complete the

operation.

Device	Configuration		BACnet Object
BACnet IP Server	Device name	Test	
Modbus Master I	Assign IP Mode	Manual Assign	
Node(1)	IP Address	192.168.0.10	
Read Holding Registe	Subnet Mask	255.255.255.0	
	Default Gateway	192.168.0.1	
💼 Preset Multiple Regist	DNS1	0.0.0	
Modbus Master II	DNS2	0.0.0	
	Byte-exchange	Disable	
	BACnet IP Port	47808	
	Device Instance	100	
		Hri	nt
	You can config the following pa	rameter:Assign IP Mode IP Address.Subnet Mask	Default Gateway、 DNS1,DNS2,BACnet IP Port and BACnet IP D
	Instance。		· · · · · ·

Note: The parameters are saved in the document, you can make changes to the data inside but please ensure correctness of the data, or incorrect data will be processed in accordance with the default values. Do not change the data keyword, and do not add spaces.

Do not change the keyword of data, and do not add spaces.

Save As		2 🔀
Save in: 😡	Desktop	• = 🖆 🛅 •
My Docum	ter	
File name: Save as type:	 bt	Save Cancel





4 Typical Application

BAM-360 can connect Modbus slave devices to Ethernet bus. BAM-360 is a bridge in the communication, and completes the conversation between BACnet and Modbus RTU.

The following is the typical application of BAM-360.



For example: The above chart multifunction energy monitoring instrument is a current measuring meter with Modbus slave station interface, the measurement of the current value is stored in the address 40001. In the BM-123, configure the No.03 function code, start address is 0 (corresponds to the Modbus register 40001 address), and then the BM-123 will be automatically mapped to the BACnet object AnalogInput (analog input). On the BACnet master PC, the current value can be observed through corresponding AnalogInput.






5 Installation

5.1 Machine Dimension

Size: 1.57 in (width)*4.92 in (height)*4.33 in (depth)







5.2 Installation Method

Using 35mm DIN rail

